

HIGH TEMP DISHMACHINE



DESCRIPTION:

This product is an economical liquid product that is formulated to be used with either low temperature dishwashing machines (using a sanitizer) or high temperature dishwashing machines with a dishmachine detergent only. This product is very concentrated and very economical to use. Our product is formulated with a special ingredient that prevents the white, alkaline residue that generally builds up inside your dishwashing machine.

CAUTIONS:

Highly Alkaline liquid. Contact with skin and eyes may cause severe irritation. Harmful if swallowed. Flood with water if splashed into eyes. Flush with water for 15 minutes and consult a physician immediately. If ingested, drink large amounts of milk, milk of magnesia or gelatin, or if these are not available, drink large amounts of water. Do not induce vomiting. Obtain prompt medical attention. Triple rinse empty containers before disposal in an authorized landfill site.

DIRECTIONS:

Range Of Use Concentration With Institutional Alkalinity Test Kit: Use range is 0.1% to 0.3% or 2 to 6 drops (each drop = 0.05%) using a 10ml sample and 3 drops of Phenolphthalein Indicator. Select actual use concentration to handle water hardness and soil load.

NOTE: To properly titrate, adjust for raw water alkalinity by titrating water just as you would a detergent solution. Subtract that number from total drop titration to derive intended detergent concentration.

Example: Raw water titrate 2 drops, total drop titration equals 6 drops. ($602=4 \times 0.05\% - 0.2\%$).

PRECAUTION: AL USARIO: Si usted no lee Ingles, no use este producto, hasta que la etiqueta le haya sido explicada ampliamente.

TO THE USER: If you cannot read English, do not use this product until this label has been fully explained to you.

BR**ODY**
CHEMICAL

TOLL FREE: 800.488.2436
www.brodychemical.com