DRAIN OPENER LIQUID Liquido Destapador de Desagues



CAUTIONS:

CORROSIVE. This is concentrated sulfuric acid. Read all directions carefully before using product. Always wear face shield and protective clothing when applying. Do not apply this product when there are other chemicals present in drain line. When flushing drains lines use cold water never hot. Never add water to container as a violent reaction will occur. Do not allow to contact porcelain, enamel. aluminum, or chrome. Do not mix with other household chemicals. When container is completely empty, rinse with water and puncture container before discarding to prevent accidental burns. For skin contact gently wipe away acid. Immediately flood area with water, then cover with moist paste of baking soda and water. Contact physician. For eve contact, flush first with water, then with a solution of 1% baking soda and water. Call a physician immediately. If ingested, do not induce vomiting. Drink large volumes of water to reduce concentration. Follow with a solution of milk of magnesia and water or baking soda and water, then egg whites beaten with water. Seek prompt medical attention.

DIRECTIONS:

After pouring acid into drain line, place an inverted plastic pail or dish pan over drain opening to minimize hazard of back-flash or fuming. Allow product to stand in drain line for the specified time, then flush with clear, cold water. Repeat procedure if required.

For Small Drains: Add 8 oz. of product to drain. Let sit for 5 minutes, then flush for 2-3 minutes.

For 3-4" Drain: Add 1 quart of product to drain. Let sit for 15 minutes, then flush for 5 minutes.

For 6-8" Drain: Add 1/2 gallon product to drain. Let sit for 15 minutes, then flush for 5 minutes.

Buyer assumes all risk for use and/or handling of this material when such use/or handling is contrary to label instructions.

PRECAUTION: AL USARIO: Si usted no lee Ingles, no use este producto, hasta que la etiqueta le haya sido explicada ampliamente.

TO THE USER: If you cannot read English, do not use this product until this label has been fully explained to you.



TOLL FREE: 800.488.2436 www.brodychemical.com